


NOTE: The Wire Guide cannot extend past the Crossbar.



Stirrer Assembly

REPLACEMENT OF STIRRING FLOATS

Float replacement (extra floats are located inside your Water Wiggler).

1. Remove stirrer assembly from the bottom of the Water Wiggler.
2. Pull the wire guide out of the plastic crossbar.
3. Remove the old floats and place the new floats on the wire guide (see drawing for orientation).
3. Insert the wire guide back into the crossbar (center hole faces away from the floats).
4. Make sure the wire guide does not protrude past the top edge of the crossbar, and then remount the stirrer to the Water Wiggler.

ALLIED PRECISION INDUSTRIES, INC.

705 East North Street • Elburn, Illinois 60119

